# **JETE**

#### WARRANTY CARD and **USER MANUAL**

**SMARTWATCH FR11** 



e-Usermanual

#### **IMPORTIR**

#### PT. DORAN SUKSES INDONESIA

Jl. Lebak Jaya 2 Tengah No. 2, Surabaya

CUSTOMER SERVICE











# JETE

## **USER MANUAL**

SMARTWATCH FR11



Please read the instructions carefully before using the product

#### Introduction:

Thank you for choosing JETE-FR11. JETE-FR11 is a smart sports watch that will help users to achieve their ideal exercise goals.

#### Package Content:



JETE FR11



User Manual



Cable Charging

#### Start JETE-FR11:

- Download and install the "JETE CONNECT" application.
- Log in to the App and Register an account to synchronize the information that the watch needs.

The application analyzes the existing data provided every day, the user can set the display, quick functions such as sitting too long warning, phone notification, exercise and others.

#### **Connect JETE-FR11 With Smartphone:**

The JETE CONNECT Support application with the system IOS 11.0 and Android 5.0 upwards, and Bluetooth 5.0, is available on more than 150 Phones.

- 1. Enable the bluetooth on the Phone.
- 2. Download "JETE CONNAECT".











3. How to connect the watch with the user of the IOS system.

Open the application > Device > Scan For Devices > select "JATE-FR11".

4. In the search list, select the JETE-FR11 with the strongest signal indicator and confirm its connection by clicking the mark button ( ■ ) on the clock, and the blueto icon on the watch will be blue ( □ ), the Bluetooth mark is already connected.

#### Connection Bluetooth 3.0:

iPhone user support Bluetooth 5.3 + 3.0 dual bluetooth one-key Link "←" (Disesuaikan dengan petunjuk system operasi).

Android users, first have to connect to the Bluetooth cell phone function by turning on Bluetooth ---> Find JETE-FR11 ---> Click on the connection button, the bluetooth icon on the watch will be orange " " after successful, then connect the watch with the JETE Connect application, then the Bluetooth icon on your watch will become blue and Orange " ".









#### Quick Fit Strap:

JETE-FR11 consists of 2 parts (Body Jam and Rubber Strap), you can buy the rubber strap separately and customize to your wishes



#### Charge Instructions:

Charge: Connect the charger pin with the magnetic rod, you will see the charging icon on the clock. Full charging is approximately over 2 hours and you'll see the battery icon fully charged. Please clean the charger before charging the clocks,



charger before charging the clocks, to make sure that the Charger is not wet, magnetic pin is dirty and some other risks.

#### Function:

How to replace wallpaper on JETE-FR11:

- Press old on the Clock screen ---> Slide to select Wallpaper ---> then click for confirmation.
- Download more wallpapers through the JETE CONNECT application by: Open Applications ---> Devices ---> Wallpapers. You can choose "Online Dial " or "Custom Dial" with pictures from your mobile phone gallery













#### Sports:

JETE-FR11 Supports up to 100+ sports modes such as fitness, relaxation, ball games, dance classes. Including: Walking, running, treadmills, climbing, cycling, bicycle spinning, yoga, basketball, football, badminton, and some other sports. JETE-FR11 supports additional sport modes that can be customized to suit your favorite sports.



#### **Activity:**

After using the watch correctly, open the "Track Record" that is on the watch. The watch will show how many steps, calories, distances and some other parameters in a day.



#### **Heart Rate:**

Use your watch correctly, not too sharp and not too loose and make sure no green light is visible under the watch, there are 2 ways to use the heart rate feature:



- Turn on the pulse icon on the clock, and measure the heart rate manually
- Automatically adjust, to measure heart rate with intervals (Once every 15/30/60/120 minutes)

#### Stress Monitor:

After using the Watch properly, open the "Stress" menu on the watch, check how much psychological stress you're feeling.



#### SPO2:

After using the Clock properly, open the "Blood Oxygen" (SPO2) menu at the clock, the clocks need time to measure the oxygen levels in the blood.



#### Sleep:

After using the watch correctly, open the "SLEEP" menu on its functional clock to record the sleep status for 1 night.



#### Notifications:

you can see messages on mobile phones and information notifications from cell phones to clocks.



#### Schedule:

Schedule synchronization can be added in the app on the clock to remember the saved schedule.



#### Music Player:

Control the music from your phone to set the volume, and replace the songs.



#### Remote Camera:

Control the camera on your mobile phone to take remote pictures, when using it, click "Device - Camera" on the apponyour phone to set up the camera



#### Stock Market:

Open the application on the phone click device select stock market and search for stock markets, click add and then add the desired stock market.



#### World Clock:

Open the application on the phone, click device, select world clock, then select the desired region.



#### Stopwatch:

The electric timer is capable of recording time



#### Find Phone:

When the watch is connected to the phone and the app, the phone will ring after pressing this function.



#### Countdown:

Electric timer can record time



#### Alarm:

set the alarm in the app to be synchronized to the clock, a maximum of 5 alarms.



#### Weather:

See the weather.



#### **Settings:**

Brightness, language, theme, disable, restart & Factory Reset.



#### Menu Shortcuts:

- 1. No disturbance mode
- 2. Brightness settings
- 3. Settings
- 4. Clock intervals on
- 5. Find cell phones
- 6. Alarm

# 03/04 Thu

## Spesification:

Screen Size :1.85" AMOLED

Screen Resolution :240\*286 Pixels

Battery Capacity : 260 mAh

BT Range :8-10m

Working Time :3-6 Days

Standby Time :10 - 20 Days

Water Resistance : IP68

Body Material : ABS+PC Plastic

Band Material : Silicone Strap

Machine Weight :21g

#### Problems:

Heartbeat Signal Lost

- JETE-FR11 Smart Watch keeps an eye on your heart rate during exercise and your daily life.
  Sometimes the watch signal may not match. If this happens, the missing heart rate will appear on the dot line.
- If you cannot use the heart rate signal, first of all, make sure you are wearing the watch correctly, avoid fitting it too high or too low, and also not too tight or not too loose on your arm. Once adjusted, click the heart rate icon to retrieve the data. If there is still no heart rate data, check the heart rate function in the app to make sure it is active.

#### Other Problems:

If your phone cannot connect to the watch, click the Bluetooth settings on your phone and check if there is a JETE-FR11 battery. If there is, it means there is no problem in the Bluetooth signal, Please check maybe the clock is connected to another cellphone, please disconnect immediately. IOS users should click Settings - Bluetooth - Forget device and connect.

#### Caution:

- JETE-FR11 data of heart rate, blood oxygen, and blood pressure, cannot be used as a benchmark for diagnosis.
- 2. Self-diagnosis and self-treatment are dangerous. Only a qualified person can diagnose and treat high blood pressure, or other heart diseases. Please contact a doctor for further diagnosis..

- 3. The data of heart rate, blood pressure, etc. of the JETE-FR11 watch may not be completely accurate due to factors such as external and environmental interference, improper use, and the user's physical condition.
- 4.Do not give medicines and treatments on the basis of those provided by the JETE-FR11 watch, and should follow the doctor's advice, and we are not responsible for any inaccuracies about the data and consequences provided.

#### Maintenance:

# Please read the following recommendations before using JETE

- Avoid exposing the device to water vapor or humid places. This can affect the internal circuit.
- Do not use cleaning solutions to clean the device.
- Do not expose the device to extreme heat or cold, as this can damage the device or change certain plastic parts.
- Avoid exposing the device to sharp objects, as this can cause scratches and damage.
- Do not disassemble or modify the device.
- Do not drop the device, as this can damage the circuitry.
- Always store the device at room temperature.

#### **How to Warranty Claim JETE Product:**

- 1. All warranty claims can be made at the list of Authorized Outlets listed on the warranty card.
- 2. Buyers can come to an authorized Outlet or contact Customer Service +62812-1739-3609 if they want to exchange the product online.
- 3. All expedition shipping costs / product postage are borne by the buyer.
- 4. When claiming the warranty, the buyer is MANDATORY to show the completeness of the warranty:
- A purchase receipt that clearly states the name of the outlet and the date of the transaction.
- The product must still be within the specified warranty period.
- Warranty card that has been filled out.
- Box/Packing Product.
- 5. Please inform the constraints / product damage that occurs to our staff.
- 6. WARRANTY DOES NOT APPLY if USER DAMAGE is found, namely:
- BROKEN, CRACKED, BURNED, DROPPED, MODIFIED BY YOURSELF, SUBMERGED IN WATER.
- 7. If there are problems during warranty claims or other questions, please contact Customer Service +62812-1739-3609.

#### Terms and Conditions of Warranty:

- 1. This warranty is valid for 2 years for original JETE products.
- 2. This warranty is valid for the warranty period stated on the product packaging since the date of sale.
- 3. During the warranty period, the user is exempt from any replacement costs that may occur.
- 4. The user must show the warranty card and purchase receipt when applying for a warranty.
- 5. The warranty applies to functional damage:
- Disfunction.
- Audio not detected.
- Indicator off.
- Battery damage.
- 6. This warranty DOES NOT APPLY if:
- PRODUCT IS BROKEN, CRACKED, BURNED, FALLEN,
- MODIFIED YOURSELF, SOAKED IN WATER.
- Supporting accessories such as: cables, adapters, etc.
- Abnormal use, not stored properly, natural disasters, modified, or anything intentionally.
- The product has been repaired by a third party.
- The data is not filled in completely by the seller and buyer.
- Damage caused by user error.
- The product warranty period has expired.

## 2 YEARS WARRANTY



Contact Us

## **JETE WARRANTY POINTS**

