JETE

WARRANTY CARD and USER MANUAL

WEBCAM W7 PRO



e-Usermanual

IMPORTIR

PT. DORAN SUKSES INDONESIA

Jl. Lebak Jaya 2 Tengah No. 2, Surabaya

CUSTOMER SERVICE








JETE

USER MANUAL

WEBCAM W7 PRO




IMKG.1573.10.2021

Please read the instructions carefully before using the product.

Introduction Product:

Thank you for purchasing JETE product for optimal and safe performance, expected to read the instructions well before running this product.

Content Package:




W7 PRO



User Manual

Description Structure Product:



- 1. Integrated Privacy Lens Cover 5. Camera in-use LED Indicator
- 2. Full HD 1080P Glass Lens
- Microphone 1
- 4. Microphone 2

- 6. Mount
- 7. Tripod Fixing Screw

How to Use:

- Connect the USB cable to the Laptop or Computerport.
- If you are using a MAC computer, you may need to purchase a USB to USB-C adapter so that the USB Webcam cable can be inserted into the USB port.
- Make sure the USB is plugged in properly

Tips:

Regular use can keep the device in optimal condition

Spesification:

Model : W7 PRO

Pixel Physic : 200W

Resolution : HD 1080 DPI

Wide Angle Horizontal : 90 Degres

Microphone : Built-in

Connection : Plug and Play

Length Cable USB : 130cm

Sensor : 1/2.7" CMOS

Maintenance:

Please read the following recommendations before using JETE

- Avoid exposing the device to water vapor or humid places. This can affect the internal circuit.
- Do not use cleaning solutions to clean the device.
- Do not expose the device to extreme heat or cold, as this can damage the device or change certain plastic parts.
- Avoid exposing the device to sharp objects, as this can cause scratches and damage.
- Do not disassemble or modify the device.
- Do not drop the device, as this can damage the circuitry.
- Always store the device at room temperature.

How to Warranty Claim JETE Product:

- 1. All warranty claims can be made at the list of Authorized Outlets listed on the warranty card.
- 2. Buyers can come to an authorized Outlet or contact Customer Service +62812-1739-3609 if they want to exchange the product online.
- 3. All expedition shipping costs / product postage are borne by the buyer.
- 4. When claiming the warranty, the buyer is MANDATORY to show the completeness of the warranty:
- A purchase receipt that clearly states the name of the outlet and the date of the transaction.
- The product must still be within the specified warranty period.
- Warranty card that has been filled out.
- Box/Packing Product.
- 5. Please inform the constraints / product damage that occurs to our staff.
- 6. WARRANTY DOES NOT APPLY if USER DAMAGE is found, namely:
- BROKEN, CRACKED, BURNED, DROPPED, MODIFIED BY YOURSELF, SUBMERGED IN WATER.
- 7. If there are problems during warranty claims or other questions, please contact Customer Service +62812-1739-3609

Terms and Conditions of Warranty:

- 1. This warranty is valid for 2 years for original JETE products.
- 2. This warranty is valid for the warranty period stated on the product packaging since the date of sale.
- 3. During the warranty period, the user is exempt from any replacement costs that may occur.
- 4. The user must show the warranty card and purchase receipt when applying for a warranty.
- 5. The warranty applies to functional damage:
- Disfunction.
- Audio not detected.
- Indicator off.
- Battery damage.
- 6. This warranty DOES NOT APPLY if:
- PRODUCT IS BROKEN, CRACKED, BURNED, FALLEN,
- MODIFIED YOURSELF, SOAKED IN WATER.
- Supporting accessories such as: cables, adapters, etc.
- Abnormal use, not stored properly, natural disasters, modified, or anything intentionally.
- The product has been repaired by a third party.
- The data is not filled in completely by the seller and buyer.
- Damage caused by user error.
- The product warranty period has expired.





Contact Us

JETE WARRANTY POINTS

