JETE

WARRANTY CARD and USER MANUAL

OTG CARD READER CR1

e-Usermanual

IMPORTIR

PT. DORAN SUKSES INDONESIA

Jl. Lebak Jaya 2 Tengah No. 2, Surabaya

CUSTOMER SERVICE

081217393609

jete.id jeteindonesia

jeteindonesia jeteindonesia

JETE

USER MANUAL

OTG CARD READER CR1



Please read the instructions carefully
before using the product.

Product Introduction :

Thank you for purchasing JETE products. For optimal and safe performance, it is expected to read the instructions carefully before using this product.

Content Package :

CR1



Strap

User Manual

Description Structure Product :



1. Micro
2. USB-A
3. Memory Slot
4. SDHC Slot
5. USB-A
6. Type-C

How to use :

- Plug one end of the Card Reader (USB-A/Type-C/Micro) into the appropriate port on your device.
- Insert the storage media such as memory/SDHC/Flashdisk into the appropriate slot on the Card Reader, making sure it is installed correctly and not upside down.
- Wait a few moments for the device to detect the storage media.
- After succesful detection you can access the data
- You can copy, move, delete or view files and holders on the storage media.
- When finished accessing the data, don't forget to eject the storage media.



Spesifikasi produk :

Model	: CR1
6 in 1 Connection	: Type-C, USB, Micro, Micro SD, SD Card, Flashdisk
Support	: WIN XP/7/8/10, MAC OS 10.2.8 atau diatasnya, Linux
Material	: Alumunium + ABS + PVC
Size	: 90*21.6*12mm
Weight	: 23g

Maintenance :

Please read the following recommendations before using JETE

- Avoid exposing the device to water vapor or humid places. This can affect the internal circuit.
- Do not use cleaning solutions to clean the device.
- Do not expose the device to extreme heat or cold, as this can damage the device or change certain plastic parts.
- Avoid exposing the device to sharp objects, as this can cause scratches and damage.
- Do not disassemble or modify the device.
- Do not drop the device, as this can damage the circuitry.
- Always store the device at room temperature.

How to Warranty Claim JETE Product :

1. All warranty claims can be made at the list of Authorized Outlets listed on the warranty card.
2. Buyers can come to an authorized Outlet or contact Customer Service +62812-1739-3609 if they want to exchange the product online.
3. All expedition shipping costs / product postage are borne by the buyer.
4. When claiming the warranty, the buyer is MANDATORY to show the completeness of the warranty:

- A purchase receipt that clearly states the name of the outlet and the date of the transaction.
- The product must still be within the specified warranty period.
- Warranty card that has been filled out.
- Box / Packing Product.

5. Please inform the constraints / product damage that occurs to our staff.
6. WARRANTY DOES NOT APPLY if USER DAMAGE is found, namely :

- BROKEN, CRACKED, BURNED, DROPPED, MODIFIED BY YOURSELF, SUBMERGED IN WATER.

7. If there are problems during warranty claims or other questions, please contact Customer Service +62812-1739-3609

Terms and Conditions of Warranty :

1. This warranty is valid for 2 years for original JETE products.

2. This warranty is valid for the warranty period stated on the product packaging since the date of sale.

3. During the warranty period, the user is exempt from any replacement costs that may occur.

4. The user must show the warranty card and purchase receipt when applying for a warranty.

5. The warranty applies to functional damage:

- Disfunction.
- Audio not detected.
- Indicator off.
- Battery damage.

6. This warranty DOES NOT APPLY if:

- PRODUCT IS BROKEN, CRACKED, BURNED, FALLEN,
- MODIFIED YOURSELF, SOAKED IN WATER.
- Supporting accessories such as: cables, adapters, etc.
- Abnormal use, not stored properly, natural disasters, modified, or anything intentionally.
- The product has been repaired by a third party.
- The data is not filled in completely by the seller and buyer.
- Damage caused by user error.
- The product warranty period has expired.

2 YEARS WARRANTY

NEW REPLACEMENT FOR ANY FAULTS *T&C

Contact Us

JETE WARRANTY POINTS