


JETE

USER MANUAL

POWERBANK B7 20.000mAh




IMKG.2107.09.2020

Please read the instructions carefully
before using the product


Product Introduction :

Thank you for purchasing JETE products. For optimal and safe performance, it is expected to read the instructions carefully before using this product.

Content Package :



B7
20.000mAh




Pouch



User
Manual


Description Structure Product :



- | | |
|--------------------|-----------------|
| 1. Lightning Cable | 4. Port USB-A |
| 2. LED Display | 5. Power Button |
| 3. Port USB-C | 6. USB-C Cable |

How to Use :

This product is indicated for digital devices with input.



- Portable rechargeable powerbank according to powerbank specifications.
- Connect to mobile phones and various types of rechargeable devices.
- Has AUTO DETECT current technology.
- LED Indicator, to monitor the level of capacity available on the powerbank.

Note :

Powerbank charging time to full is 2 hours (fast charging).

Maintenance :

1. If the battery is not replaced properly, there is an explosion risk. Only batteries of the same type or equivalent type can be used for replacement. And only maintenance personnel can replace it, not ordinary personnel.
2. Batteries must not be exposed to environments such as direct sunlight, fire or similar overheating conditions.
3. If consumers charge with a power adapter, should purchase a power adapter that has obtained CCC certification and meets the standard requirements for use.
4. Product should be placed on the desktop when using, if it needs to be used in contact with the human body, the contact time should be less than 10 seconds.
5. Do not use after soaking in water.



Maintenance :

1. If the battery is not replaced properly, there is an explosion risk. Only batteries of the same type or equivalent type can be used for replacement. And only maintenance personnel can replace it, not ordinary personnel.
2. Batteries must not be exposed to environments such as direct sunlight, fire or similar overheating conditions.
3. If consumers charge with a power adapter, should purchase a power adapter that has obtained CCC certification and meets the standard requirements for use.
4. Product should be placed on the desktop when using, if it needs to be used in contact with the human body, the contact time should be less than 10 seconds.
5. Do not use after soaking in water.



JETE

**WARRANTY CARD and
USER MANUAL**

POWERBANK B7 20.000mAh



e-Usermanual

IMPORTIR

PT. DORAN SUKSES INDONESIA

Jl. Lebak Jaya 2 Tengah No. 2, Surabaya

CUSTOMER SERVICE

 081217393609

 jete.id  jeteindonesia

 jeteindonesia  jeteindonesia

How to Warranty Claim JETE Product :

1. All warranty claims can be made at the list of Authorized Outlets listed on the warranty card.
2. Buyers can come to an authorized Outlet or contact Customer Service +62812-1739-3609 if they want to exchange the product online.
3. All expedition shipping costs / product postage are borne by the buyer.
4. When claiming the warranty, the buyer is MANDATORY to show the completeness of the warranty:
 - A purchase receipt that clearly states the name of the outlet and the date of the transaction.
 - The product must still be within the specified warranty period.
 - Warranty card that has been filled out.
 - Box / Packing Product.
5. Please inform the constraints / product damage that occurs to our staff.
6. WARRANTY DOES NOT APPLY if USER DAMAGE is found, namely:
 - BROKEN, CRACKED, BURNED, DROPPED, MODIFIED BY YOURSELF, SUBMERGED IN WATER.
7. If there are problems during warranty claims or other questions, please contact Customer Service +62812-1739-3609

Terms and Conditions of Warranty :

1. This warranty is valid for 2 years for original JETE products.
2. This warranty is valid for the warranty period stated on the product packaging since the date of sale.
3. During the warranty period, the user is exempt from any replacement costs that may occur.
4. The user must show the warranty card and purchase receipt when applying for a warranty.
5. The warranty applies to functional damage:
 - Disfunction.
 - Audio not detected.
 - Indicator off.
 - Battery damage.
6. This warranty DOES NOT APPLY if:
 - PRODUCT IS BROKEN, CRACKED, BURNED, FALLEN,
 - MODIFIED YOURSELF, SOAKED IN WATER.
 - Supporting accessories such as: cables, adapters, etc.
 - Abnormal use, not stored properly, natural disasters, modified, or anything intentionally.
 - The product has been repaired by a third party.
 - The data is not filled in completely by the seller and buyer.
 - Damage caused by user error.
 - The product warranty period has expired.

**2 YEARS
WARRANTY**

**NEW REPLACEMENT
FOR ANY FAULTS *T&C**



Contact Us

JETE WARRANTY POINTS

